SelfLoops Repeater




What You Need

One or more SelfLoops Repeaters (it depends on the space you want to cover)

WiFi coverage of the area

One Android device or iPad or Apple TV to act as a receiver

The Selfloops Repeaters and Receivers must be connected to the same WiFi network





The SelfLoops Repeater

A repeater is an Android device with installed our Selfloops Repeater application

The device must have USB Host support

An ANT+ stick is required (e.g. Garmin ANT stick)



Install the following apps from the Google Play store:

SelfLoops Repeater

ANT Radio Service

ANT USB service

An Android box is recommended as it can be always connected to the power outlet

Configure the SelfLoops Repeater

Plug the ANT+ accessory in the USB port of the Android device.

Select "Use by default for this USB device"

Press OK

Now ANT is enabled and the Repeater is ready to start

Please make sure that the Repeater is connected to the same WiFi network of the Receiver device

The SelfLoops Repeater

The application will show the list of active sensors, the sensors IDs and types

9:28		* 🦬 ax +
START SESSION		SELFLOOPS REPEATER
Device	#ID	Status
HRM	100	
HRM	125	
PWR	347	
CAD	1023	

Contacts

SelfLoops Group Fitness webpage:

http://www.selfloops.com/products/groupfitness.html

email: sales@selfloops.com

